LIMITING ROTATION

- 1. Orient shaft with the flat opposite position #2. See PREPARATION.
- which is half a position counterclockwise (shaft end view) of position #1. This creates a stop between the last and first positions of rotation,
- maximum positions, only 1 pin (washer)
- 4. For other switches, place second pin in the hale which is clockwise of desired last position. (For Series 42/44, this is the hole which is NUM-BERED for the last desired position). NOTE: For switches of 2 or more poles. the last position MUST be on Pole #1. For example, for a 2-pole, 36° throw switch, the hole clockwise of position
- Add appropriate retainer or seal pieces. See PREPARATION. NOTE: If there is a thin metal washer. add it first; otherwise seal goes first

a black seal embedded in it, check the marking on the seal to see which side goes next to switch.

Mount switch with lockwasher and nut(s).


SHAFT

BLTN 474, 109

- 2. Place first pin (or washer) in the hole
- 3. For switches of 1 pole per deck with is required; discard second pin (washer).
- number 3, 4, or 5.
- NOTE: If there is a double flatted nut with

GRAYHILL, INC.

INSTRUCTIONS Adjustable Stop Switches With Standard Circuitry



PREPARATION

Piece Parts. There are 3 types of parts in or on the switch or in a bag.

- 1. Stop Pins (2), or angled Stop Washers (2)
- 2. Retainers and Seals Any of the following: double flatted thick metal nut, thin seal washer, plain flat metal washer, adhesive sticker, and/ or a round knurled nut (optional)
- Mounting Hardware: hex nut(s) & internal toothed lockwasher Stop Holes. These are located in the front plate, halfway between switch positions.
- Switch Positions. These are equivalent to the location of the terminals. See numbers on the side of switch or the end plate.


CONTINUOUS ROTATION

Use only for switches with 1 pole per deck.


- Discard stop pins (or stop washers) and unnecessary retainers.
- Mount the switch, using lockwasher and hex nut(s). (continued on next page)

LIMITING ROTATION


- 1. Orient shaft with the flat opposite position #2. See PREPARATION.
- 2. Place first pin (or washer) in the hole which is half a position counterclockwise (shaft end view) of position #1. This creates a stop between the last and first positions of rotation,
- 3. For switches of 1 pole per deck with maximum positions, only 1 pin (washer) is required; discard second pin (washer).
- For other switches, place second pin in the hole which is clockwise of desired last position. (For Series 42/44, this is the hole which is NUM-BERED for the last desired position). NOTE: For switches of 2 or more poles. the last position MUST be on Pole #1. For example, for a 2-pole, 36° throw switch, the hole clockwise of position number 3, 4, or 5.
- Add appropriate retainer or seal pieces. See PREPARATION.
 - NOTE: If there is a thin metal washer. add it first; otherwise seal goes first NOTE: If there is a double flatted nut with a black seal embedded in it, check the marking on the seal to see which side goes next to switch.
- Mount switch with lockwasher and nut(s).







INSTRUCTIONS Adjustable Stop Switches With Standard Circuitry



PREPARATION

Piece Parts. There are 3 types of parts in or on the switch or in a bag.

- Stop Pins (2), or angled Stop Washers (2)
- 2. Retainers and Seals Any of the following: double flatted thick metal nut, thin seal washer, plain flat metal washer, adhesive sticker, and/ or a round knurled nut (optional)
- 3. Mounting Hardware: hex nut(s) & internal toothed lockwasher Stop Holes. These are located in the front plate, halfway between switch positions.
- Switch Positions. These are equivalent to the location of the terminals. See numbers on the side of switch or the end plate.

CONTINUOUS ROTATION

Use only for switches with 1 pole per deck.

- Discard stop pins (or stop washers) and unnecessary retainers.
- 2. Mount the switch, using lockwasher and hex nut(s). (continued on next page)

GRAYHILL, INC

BLTN 474, 1090